
DELUXE SERIES 5-ROW 21' BLEACHER

MODEL 1183-521MESHG 5-ROW 21' STEEL WITH MESH GUARDRAIL MODEL 1183-521MESHA 5-ROW 21' ALUMINUM WITH MESH GUARDRAIL

MODEL 1183-521VBGRG 5-ROW 21' STEEL WITH VBGR GUARDRAIL MODEL 1183-521VBGRA 5-ROW 21' ALUMINUM WITH VBGR GUARDRAIL (VBGR = VERTICAL BAR GUARDRAIL)

Deluxe Series designed for dependability and trouble-free maintenance. Featuring 6" rise from row to row with nominal 12" aluminum planks for seats and 10" for footboards. And optional 2" x 6" ground sills



Bleacher Frames are fabricated from 2" x 2" x 3/16" steel or aluminum angle. Frames are welded into a single unit. Frames may have optional 2" x 6" ground sills at every point where frames are in contact with the ground.

Deluxe Series Bleachers conform to the requirements of ICC 300-2012.

<u>Seat and Foot Planks:</u> Seat planks are nominal 2"x12"x21' and foot planks are nominal 2"x10"x21' extruded, ribbed aluminum. The edges and tops of planks shall be ribbed. The ribbed pattern, non-slip surface, is designed for safety and comfort. All exposed ends shall have aluminum caps fastened to the underside of the plank. Planks secure to each frame with two friction-type aluminum mounting clips capable of securing the plank against movement under a horizontal force of 400 lbs. All hardware is provided.


Finish: All fasteners shall be zinc plated.



Date: 4/28/2021	PRODUCT NAME			
Rev: A	5 ROW DELUXE 21FT			
Drawn: JBN	MODEL NO.			
	1183-521			
Sheet: 1 of 16				

BOM PARTS & FASTENERS


ITEM NO.	PART NUMBER	DESCRIPTION	
1	ROW5A or ROW5G	BLEACHER 5-ROW FRAME	4
2	CIBLB74.625	BLEACHER BRACE 74-5/8" LONG	6
3	CIBLB76.375	BLEACHER BRACE 76-3/8" LONG	3
4	RMPLK21-12	ALUMINUM PLANK 12"x 252" ANODIZED	5
5	RMPLK21-10	ALUMINUM PLANK 10"x 252" ANODIZED	8
6	VCIAECP212	2"x12" ALUM. END CAP	10
7	VCIAECP	2"x10" ALUM. END CAP	16
8	VCIACLP	BOLT CLIP FOR 10" & 12" ALUMINUM PLANK	104
9	BLSEATADPT	DELUXE SEAT ADAPTER 2" x 11"	20
10	HWCB516114	5/16-18 X 1-1/4 CARRIAGE BOLT GRADE 2 ZINC	88
11	HWCB5163	5/16-18 X 3 CARRIAGE BOLT GRADE 2 ZINC	16
12	HWFLWA516	5/16 FLAT WASHER	120
13	HWLN516	5/16 NYLOK NUT ZINC	120
14	HWLN38	3/8 NYLOK NUT ZINC	33
15	HWFLWA38	3/8" Flat Washer	58
16	HWHB38112	3/8-16 X 1 1/2 GR5 C/S ZINC HEX BOLT (1000)	25
17	HWTEX1034	#10 x 3/4 SELF TAPPING SCREW	52
18	CIFFRAMER	REAR F-FRAME PANEL SUPPORT	4
19	CIFFRAMES-RT	RIGHT F-FRAME PANEL SUPPORT	1
20	CIFFRAMES-LT	LEFT F-FRAME PANEL SUPPORT	1
21	CIVBGRREAR OR VCIMESHPANELREAR	RAILING LONG REAR PANEL	2
22	CIVBGRMID OR WCIMESHPANELMID	RAILING SHORT REAR PANEL	1
23	CIVBGRSIDE OR VCIMESHPANELSIDE	RAILING SIDE PANEL	2
24	VCIPANELCLAMP138	1-3/8" X 1-3/8" PANEL CLAMP CLAMPS - PAIR	8
25	HWUB516112	5/16 x 1-1/2 x 2-11/16 U bolt	8
26	HWCB38214	3/8" -16 x 2-1/4" Carriage Bolt	8
	L		





Date: 5/4/2021	PRODUCT NAME		
Rev: A	5 ROW DELUXE 21FT		
Drawn: JBN	MODEL NO.		
	1183-521		
Sheet: 2 of 16			


- 1) Check materials received with the BOM to make sure that all components are included and to assure that the unit is complete.
- 2) Installing End Caps Item on Seat and Foot Planks: 2" x 12" & 2" x 10" end caps Item 6 7. Align and assemble all end caps to aluminum planks. Secure using #10 x 3/4" Item 17 self-tapping screw in two locations on the underside of the clip/plank.





Date: 5/4/2021 Rev: A	5 ROW DELUXE 21FT	
Drawn: JBN Sheet: 3 of 16	MODEL NO. 1183-521	

3) Locate the four Bleacher 5-Row Standard Frame Item 1 and set on a level surface on 73" centers.




SPORT & SITE ELEMENTS FOR LIFE OUTSIDE
www.PWATHLETIC.com 1-800-687-5768

Sheet: 4 of 16

Date: 5/4/2021 Rev: A	PRODUCT NAME 5 ROW DELUXE 21FT
Drawn: JBN	MODEL NO.
	1183-521


4) To Install Cross Braces: a) Locate three sets of braces measuring 76-3/8" and 74-5/8" Long Item 3 2 . Install on the backside of the Bleacher Frames using 3/8" x 1-1/2" Hex Bolt Item 16 , Washers Item 15 , and Lock Nut Item 14 provided using the top and bottom slots in the frame and center of Braces as shown. Repeat steps to assemble remaining sets of braces to the other bleacher frames. At all installation points, install washers and nuts but leave hardware loose until assembly is complete for easy installation.


NOTE: Two washers are provided to use at every hex bolt location.





Date: 5/4/2021 Rev: A	5 ROW DELUXE 21FT
Drawn: JBN	MODEL NO. 1183-521
Sheet: 5 of 16	








Date: 5/4/2021
Rev: A
Drawn: JBN
Sheet: 6 of 16

PRODUCT NAME
5 ROW DELUXE 21FT

MODEL NO.

5) To Install Cross Braces a) Locate three braces measuring 74-5/8" Item (2). Install on the backside of the second row of Bleacher Frames using 3/8" x 1-1/2" Hex Bolt Item (16), Washers Item (15), and lock nut Item (14) for the top, bottom slots and center between Braces. Repeat steps to assemble remaining sets of braces to the other bleacher frames. At all installation points, install washers and nuts but leave hardware loose until assembly is complete for easy installation.

NOTE: Two washers are provided to use at every hex bolt location.







Sheet:

7 of 16

Date: 5/4/2021 Rev: A	PRODUCT NAME 5 ROW DELUXE 21FT
Drawn: JBN	MODEL NO. 1183-521






DETAIL D ENLAGED FROM SHEET #7 SCALE 1:5



Date: 5/4/2021		PRODUCT NAME			
Rev:	Α	5 ROW DELUXE 21FT			
Drawn:	JBN	MODEL NO.	1183-521		
Sheet:	8 of 16		1100 021		

6) To Install Seat and Foot Planks: a) First place deluxe seat adapter on each seat upright then install the Bolt Clip For 10" & 12" Aluminum Plank Item 8 using 5/16" x 1-1/4" carriage bolts Item 10, washer Item 12, and lock nuts 13 on top of the seat and foot board supports. To install clips for riser planks useing 5/16" x 3" carriage bolts Item 11, washer Item 12, and lock nuts 13. Give nuts about 3/4 turn (just enough to secure). Turn Bolt Clips Item 8 perpendicular to the frames.




SPORT & SITE ELEMENTS FOR ILFE OUTSIDE
www.PWATHLETIC.com 1-800-687-5768

	Date:	5/4/2021	۲
	Rev:	Α	
	Drawn	: JBN	N
	Sheet:	9 of 16	
_			

PRODUCT NAME			
5 ROW	DEL	UXE	21FT

MODEL NO.





Date:	5/4/2021	
Rev:	Α	
Drawn:	JBN	ı
Sheet:	10 of 16	


PRODUCT NAME 5 ROW DELUXE 21FT


MODEL NO.

7) Position seat Planks, Foot Planks and Riser Planks on the supports so the Bolt Clips Item 8 are between the slots in the bottom of Planks. Reach up underneath the Seat Plank, Foot Plank, and Riser Plank to rotate the Bolt Clips Item 8 to 90° so they engage the planks. To Secure Planks to Frames center the planks on the frames Item 1. Tighten all hardware on frames and planks securely.










SECTION G-G FROM SHEET #11 SCALE 1 : 15





Date: 5/4/2021

Rev: A


Drawn: JBN

Sheet: 12 of 16

PRODUCT NAME
5 ROW DELUXE 21FT

MODEL NO.

8) Install Right, Left and Rear F-Frame Panel Support Items 18 19 20. Attach to Bleacher Frames with 3/8" x 1-1/2" hex bolts Item 16, washers Item 15 and lock nuts Item 14. Details shown on page 14.







	Date:	5/4/2021	ľ
	Rev:	Α	
	Drawn:	JBN	٨
			1
	Sheet:	13 of 16	
-			_

PRODUCT NAME		
5 ROW	DELUXE	21FT

MODEL NO.



DETAIL-T FROM SHEET #13



DETAIL-V FROM SHEET #13




Date:	5/4/2021	I
Rev:	Α	
Drawn:	JBN	ľ
		'
Sheet:	14 of 16	

PRODUCT NAME

5 ROW DELUXE 21FT

MODEL NO.


9) Install Railing Side and Rear Panels Items (21) (22) (23). Attach Railing Side Panel Item (23) to Right F-Frame Panel Support Item (19) with 5/16" U-Bolt Item (25), washers Item (12) and lock nuts Item (13) Attach Railing Rear Long Panel Item (21) to Rear F-Frame Panel Support Item (18) using 5/16" U-Bolt Item (25), washers Item (12), lock nuts Item (13), Panel Clamp Item (24), 3/8" x 2-1/2" Carriage bolts Item (26), washers Item (15) and lock nuts Item (14). Repeat with the rest of the Railing Panels.




Date:	5/4/2021	ľ
Rev:	Α	
Drawn:	JBN	٨
Sheet:	15 of 16	

PRODUCT NAME		
5 ROW	DELUXE	21FT


MODEL NO.



DETAIL W SCALE 1:5



DETAIL X SCALE 1:5



DETAIL Y SCALE 1:5

10) Installing (Optional) Ground Sills (wood measuring 2" x 6" x 96"): a) Center one ground sill under each bleacher frame so the ends are evenly spaced and are centered from side to side. Mark the (4) hole locations in each bleacher frame on each of the ground sills and drill 1/4" x 1" deep pilot holes. DO NOT drill completely through the ground sills. b) Attach the ground sills to the bottom of the bleacher frames with 5/16" x 1-1/4" lag bolts and flat washers provided.



Date:	5/4/2021	ľ
Rev:	Α	
Drawn:	JBN	١
		Ĭ
Sheet:	16 of 16	
		_

PRODUCT NAME		
5 ROW	DELUXE	21FT

MODEL NO.