




# SINGLE SIDED BIKE RACK

MODEL 1616-06      6 SPACE RACK (90 LBS)  
MODEL 1616-08      8 SPACE RACK (97 LBS)  
MODEL 1616-16      16 SPACE RACK (148 LBS)




MODEL	L	x	W	x	H
MODEL # 1616-06 = 6 SPACE RACK	51"		16"		30"
MODEL # 1616-08 = 8 SPACE RACK	67"		16"		30"
MODEL # 1616-16 = 16 SPACE RACK	130"		16"		30"



## SPECIFICATIONS:

One of our most popular bike racks featuring 1-5/8" O.D. steel frame with 1-3/8" O.D. steel vertical rails. Can be entered from either side and number of spaces can be doubled with the add-on rack. T-fittings and in-line rail fittings are used to assemble the rack.

Finish: Galvanized or Powder Coated

	Date: 4/23/2013	<b>SPECIFICATION / INSTALLATION INSTRUCTIONS</b> <b>SINGLE SIDED BIKE RACK</b>
	Rev:	
	Drawn: AY	MODEL NO.  <b>1616</b>
	Sheet: 1 of 2	

# MODEL 1616-06 6 SPACE RACK




## INSTALLATION INSTRUCTIONS:

1. Attach spreader brace rail to bent end frame with T-fittings and carriage bolts. Bottom of T-fitting to be attached approximately 3" from bottom of bent end.
2. Attach T-fittings on both end frames. Tighten finger tight until rack is fully assembled.
3. Attach welded rack to bent end frame and spreader brace rail with T-fittings and carriage bolts. The T-fittings will be centered on the bent end and spreader brace rail.
4. Attach other end frame in same manner.
5. Attach horizontal brace pipes to end frames with T-fittings and carriage bolts. Note: The T-fittings will attach at ground level.
6. Level and plumb. Tighten all bolts.
7. Drill holes through each T-fitting and underlying pipe using the drill bit provided, and hammer in drive pins.

Note: Bike rack is pre-drilled with holes for standard surface mount. Hardware is not provided for anchoring.

MODEL 1616  
(6, 8, & 16 SPACES)

Packing Slip	Qty
Welded 6 Space Rack	1
Bent Ends	2
Horizontal Brace Pipe (1-5/8" x 45-1/2")	1
Spreader Pipe (1-5/8" x 11-1/2")	2
Vertical Support Pipe (1-5/8" x 30")	2
Hardware Kit	Qty
T-Fittings 1-5/8" (pair)	12 Pair
#10 x 1/2" Round Head Drive Pins	24
5/16" x 2-1/4" Carriage Bolts	12
5/16" Nylock Nuts	12
#25 Drill Bit	1

	Date: 4/23/2013	<b>SPECIFICATION / INSTALLATION INSTRUCTIONS</b> <b>SINGLE SIDED BIKE RACK</b>
	Rev:	
	Drawn: AY	MODEL NO.  <b>1616</b>
	Sheet: 2 of 2	